



TO BE USED ONLY WITH PLANUS CONTROLLER “CTRL-1P” (single button version) or “CTRL-2P” (double button version).

Respect the matching of the versions for Slim Wall Switch and Controller.

INFO	
Supplied frame:	Bticino Living—white color
Alternative frame (not supplied)	Vimar Eikon ; Vimar Plana
CABLE LENGHT (Wall Switch):	2 mt (6 x 0.25)
CONNECTOR:	TYCO 280365
CABLE LENGHT (Controller):	1,5 mt (6 x 2,5)
DEGREE OF PROTECTION:	IP44
NORMS:	EN 10133—EN 55032—EN 55024



SINGLE BUTTON VERSION

This control panel causes the toilet to flush automatically, leaving a certain amount of water in the bowl.




DOUBLE BUTTON VERSION

The toilet activated by two button control panel leaves the bowl completely empty when not in use. The "Before Use" button must be pressed to fill the bowl ready for use.

INTEGRATED TANK LEVEL INDICATORS

Slim Wall Switch has a Level indicator, to check the status of the black water tank. To operate, a dedicated sensors must be connected to Controller



**GREEN LIGHT
POWER ON
TANK LEVEL: LOW**

**RED LIGHT
TANK FULL**


INSTALLATION

CONTROLLER:

- Fix with the supplied screws in a hidden place (**possibly, guarantee the ease of access for maintenance**)
- Connect the plugs (see diagram)

WALL SWITCH:

- Fix the frame with 2 screws (supplied) to the wall Route the wire to the Controller and plug to dedicated socket




SET THE WATER LEVEL

RECOMMENDED WATER AMOUNT (LEVEL) IS ABT. 1CM ABOVE THE TOILET'S DRAINAGE HOLE AT THE END OF "BEFORE USE" FUNCTION (DOUBLE BUTTON VERSION) OR WHILE UNATTENDED (SINGLE BUTTON / FAMILY VERSION).


TUNE THE KNOB AT THE BACK OF THE PANEL TO REDUCE OR EXTEND THE TIMING FOR WATER INLET



CONNECTIONS (SIMPLIFIED)




12/24Vdc DIAGRAM




230Vac DIAGRAM

NOTE: for 230Vac systems an additional TRANSFORM BOX item (PW.030.00) is supplied with toilets.




DIMENSIONS

SLIM Wall Switch





Controller



To TOUCH or SLIM wall switch

KNOB to set water level



www.planus.eu

